

## SD25HD User Instructions



### Turning On:

1. Touch the sensor for a couple of seconds until the power light comes on.
2. Remove finger.

### Powering Up:

- The unit's LEDs will flash for a few seconds while powering as the system is initializing communications with the SoundDock 10 processor.

### Pairing:

1. Momentarily touch the sensor.
2. The system will play a tone and the Blue LED will flash rapidly to indicate it is discoverable.
3. Select "SD10HD" on the device list on your source device and pair with it.
4. When pairing is complete, a tone will be played.

### Streaming:

- You can now stream audio.

### Forced Disconnection/Pairing Mode:

- Momentarily touch the sensor to force disconnection of a connected device and enter pairing mode.

### Powering Down:

1. Touch the sensor for a few seconds. The red light will extinguish.
2. The Bluetooth system powers down.
3. All LEDs extinguish. Note: powering down the SD10HD saves remarkably little power. It is primarily to prevent unwanted connecting and streaming.

### LED Status:

- **Both Off:** Bluetooth powered down.
- **Red On:** Bluetooth system on. Main dock system powered down.
- **Blue and Red Alternating Flashing:** System initializing communications with the SoundDock 10 processor.
- **Blue Slow Blip:** Paired and ready to play, no stream (paused). Main dock powered down. (If you pause your source device, it will enter this mode after about 10 seconds.)
- **Blue Full On:** Connected and source device is streaming.